



## MAIN FUNCTIONS

### A- standby key [3]

Key [3], if pressed for 3 seconds, allows the controller status to be switched over between output activity and standbyby.

### B- Info key [5]

Press and immediately release button [5] to get access to the info menu; with the keys [4] or [1] select the data to be displayed. Press key [5] to display its value. To exit from this menu, press key [3] or wait for 5 sec.

### C- Defrost key [2]

Keep key [2] pressed for 2s to get a manual defrost started.

### D- To modify the control setpoint, proceed as follows:

- press shortly and release key [1] or key [4]: on the display the icon set will be activated and the active setpoint will be displayed;
- with keys [1] and [4] set the desired value;
- to save the newly programmed value press key [5] or wait for 5s;
- in order NOT to save the new value, press key [3].

E- You have access to the configuration of parameters (SETUP) by keeping the buttons [6]+[3] pressed for 5s.